

## Air200/Air200S/Air201 之间的区别

管脚	Air200	Air200S	Air201	说明 (Air201所有的GPIO都有中 断功能)
1	GND	GND	GND	
2	ANT	ANT	ANT	
3	GND	GND	GND	
4	GND	GND	GND	
5	GPIO_6	GPIO_6	GPIO_28	GPIO序列号不同
6	NET_LED/GPIO_15	NET_LED/GPIO_15	NET_LED/32K_OUT/GPIO_33	GPIO序列号不同
7	VRTC	ADCO	ADCO	Air200S和Air201 改成了ADC输入
8	GND	GND	GND	
9	MICP	MICP	MICP	
10	MICN	MICN	MICN	
11	RECP	SPKP	SPKP	Air200S和Air201 改成了Speaker输出，可以直接驱动8欧姆喇叭
12	RECN	SPKN	SPKN	
13	GND	GND	GND	
14	VDDIO	VDDIO	VDDIO	
15	RESET_N	RESET_N	RESET_N	
16	GPIO_24/I2C2_SCL	GPIO_24/I2C2_SCL	UART2_RTS/GPIO_6/I2C3_SCL	GPIO序列号不同
17	GPIO_25/I2C2_SDA	GPIO_25/I2C2_SDA	UART2_CTS/GPIO_7/I2C3_SDA	GPIO序列号不同
18	HOST_RXD	HOST_RXD	HOST_RXD	
19	HOST_TXD	HOST_TXD	HOST_TXD	
20	UART2_TXD/GPIO_13	UART2_TXD/GPIO_13	UART2_TXD/GPIO_5	GPIO序列号不同
21	UART2_RXD/GPIO_8	UART2_RXD/GPIO_8	UART2_RXD/GPIO_4/SPI2_DI	GPIO序列号不同
22	UART1_RXD/GPO_8	UART1_RXD/GPO_8	UART1_RXD/GPIO_0/SPI2_CLK	GPIO序列号不同
23	UART1_TXD/GPO_6	UART1_TXD/GPO_6	UART1_TXD/GPIO_1/SPI2_CS0	GPIO序列号不同
24	GPIO_5	GPIO_5	GPIO_32	GPIO序列号不同
25	GPIO_14	GPIO_14	GPIO_31	GPIO序列号不同
26	GPIO_3	GPIO_3	GPIO_29	GPIO序列号不同
27	GPIO_1	GPIO_1	GPIO_30	GPIO序列号不同
28	SIM_RST	SIM_RST	SIM_RST	
29	SIM_CLK	SIM_CLK	SIM_CLK	
30	SIM_DAT	SIM_DAT	SIM_DAT	
31	SIM_VDD	SIM_VDD	SIM_VDD	
32	GND	GND	GND	
33	UART1_CTS/GPO_9	UART1_CTS/GPO_9	UART1_CTS/GPIO_3/SPI2_DO	GPIO序列号不同
34	UART1_RTS/GPIO_4	UART1_RTS/GPIO_4	UART1_RTS/GPIO_2/SPI2_CS1	GPIO序列号不同
35	PWRKEY	PWRKEY	PWRKEY	
36	GND	GND	GND	
37	GND	GND	GND	
38	VBAT	VBAT	VBAT	
39	VBAT	VBAT	VBAT	